

Product line	Model	Driver
Single Board Computers	C3131ES-IM-AA	<a href="#">Ready</a>
Single Board Computers	C5134ES-IM-AA	<a href="#">Ready</a>
Single Board Computers	C7136ES-IM-AA	<a href="#">Ready</a>
Industrial Motherboards	H610A-IM-A	<a href="#">Ready</a>
Industrial Motherboards	H610I-EM-A	<a href="#">Ready</a>
Industrial Motherboards	H610I-IM-A	<a href="#">Ready</a>
Industrial Motherboards	H610M-IM-A	<a href="#">Ready</a>
Industrial Motherboards	H610T-EM-A	<a href="#">Ready</a>
Industrial Motherboards	N100I-EM-A	<a href="#">Ready</a>
Single Board Computers	N200S-IM-AA	<a href="#">Ready</a>
Single Board Computers	N305S-IM-AA	<a href="#">Ready</a>
Single Board Computers	N97S-IM-AA	<a href="#">Ready</a>
Single Board Computers	N97T-IM-A	<a href="#">Ready</a>
Industrial Motherboards	Q670EA-IM-A	<a href="#">Ready</a>
Industrial Motherboards	Q670EI-IM-A	<a href="#">Ready</a>
Industrial Motherboards	Q670EM-IM-A	<a href="#">Ready</a>
Industrial Motherboards	Q670M-EM-A	<a href="#">Ready</a>
Industrial Motherboards	R680EA-IM-A	<a href="#">Ready</a>
Industrial Motherboards	R680EA-IM-Z	Ready*
Industrial Motherboards	R680EI-IM-A	<a href="#">Ready</a>
Industrial Motherboards	W680I-EM-A	<a href="#">Ready</a>
Single Board Computers	X7211RE-IM-A	<a href="#">Ready</a>
Single Board Computers	X7213RE-IM-A	<a href="#">Ready</a>
Single Board Computers	X742ES-IM-AA	<a href="#">Ready</a>
Single Board Computers	X7433RE-IM-A	<a href="#">Ready</a>
Single Board Computers	X7835RE-IM-A	<a href="#">Ready</a>
Embedded Computers	EBS-S100	<a href="#">Ready</a>

Product line	Model	Driver
Embedded Computers	EBS-S110W	<a href="#">Ready</a>
Single Board Computers	C3121S-IM-AA	<a href="#">12/B</a>
Single Board Computers	C3121ES-IM-AA	<a href="#">12/B</a>
Single Board Computers	C5123S-IM-AA	<a href="#">12/B</a>
Single Board Computers	C5124ES-IM-AA	<a href="#">12/B</a>
Single Board Computers	C5143ES-IM-AA	<a href="#">12/B</a>
Single Board Computers	C7125S-IM-AA	<a href="#">12/B</a>
Single Board Computers	C7126ES-IM-AA	<a href="#">12/B</a>
Single Board Computers	C7146ES-IM-AA	<a href="#">12/B</a>
Embedded Computers	EBS-S500W	<a href="#">12/B</a>
Embedded Computers	PE2000S	<a href="#">Ready</a>
Embedded Computers	PE2100S	<a href="#">Ready</a>
Embedded Computers	PE2200U	<a href="#">Ready</a>
Embedded Computers	PE5100D	<a href="#">Ready</a>
Embedded Computers	PE5101D	<a href="#">Ready</a>
Embedded Computers	PE4000G	<a href="#">Ready</a>
Embedded Computers	PE6000G	<a href="#">Ready</a>
Embedded Computers	PE8000G	<a href="#">Ready</a>

*\*Please contact the Account Executive (AE) for the driver file. You can reach them at [ryan\\_hsieh@asus.com](mailto:ryan_hsieh@asus.com) or [fred\\_yu@asus.com](mailto:fred_yu@asus.com).*